




## Comcast Custom DVR

### 3 Device



### User Guide

## OVERVIEW

The Comcast Custom DVR 3-Device universal remote will control up to three home entertainment devices, including a Digital Video Recorder enabled Cable Box (used by Comcast Systems).

The remote control requires installing two (2) new AA batteries (included) and some easy programming to control your devices. For best results, please read and perform all instructions listed here. Also, keep this guide for future reference.

## INSTALLING BATTERIES

1. Pull back the remote control's battery cover and remove it.
2. Insert the two (2) supplied AA batteries according to the + and - marks in the battery case.
3. Push the battery cover back into place.
4. Test the unit by pressing any mode key (i.e., **AUX**, **TV**, or **Cable**). If batteries are inserted correctly, the selected mode key will light.

NOTE: When batteries need replacement, the remote control will stop operating. Replace the old batteries and the unit will be restored to its full functionality, complete with your favorite settings.

## FEATURES AND FUNCTIONS

Use the remote control's mode keys (i.e., **AUX**, **TV**, or **Cable**) to control a specific device. When pressed, the selected mode key will light, confirming your choice. Use the other keys to perform desired actions (see the following key chart).

NOTE: The selected mode will remain active until you press another mode key.

Press **AUX**, **TV**, or **Cable** once to select and control a device.

Press **Power** once to turn on or off the selected home entertainment device.

Use **Setup** for all programming sequences.

Press **All On** once to turn on or off all programmed devices in this order: **Cable**, **TV**, and **AUX**. After all devices are on, **Cable** is the active mode.

Press **ON DEMAND** once to access Comcast's ON DEMAND menu (not available in all areas).


In the **AUX** or **TV** mode, use the transport keys to control a VCR, PVR, or DVD player. To record a program on a VCR, press **REC** twice.

In the **Cable** mode, use the keys to control ON DEMAND programs.

Press **REPLAY** to replay the previous few seconds of a program.

Press **My DVR** to show a list of programs that have been recorded.

Press **LIVE** to return to watching live TV.



**Lock**

**A**

**B**

**C**

**Day**

**+**

**-**

**0**

**1**

**2**

**3**

**4**

**5**

**6**

**7**

**8**

**9**

**\***

**#**

**OK**

**Select**

**OK**

## MANUFACTURER'S CODES

### Setup Codes For Audio Amplifiers

GE	30078
JVC	30331
Soundsignal	30078
Victor	30331
Wards	30078
Yamaha	30354

### Setup Codes For Audio Receivers

ADC	30531
Aiwa	30158, 30189, 30405
Bose	31229, 31933
Capetronic	30531
Carver	30189
Demon	31360, 31104
Harman/Kardon	30110, 30189
Integra	30135
JBL	30110
JVC	30074
Kenwood	31313, 31570, 30027, 31027
Linn	30189
Magnavox	30189, 30531
Marantz	30189
Onkyo	30135, 30842
Optimus	31023, 30531
Panasonic	31308, 31518
Philips	30189, 31266
Pioneer	31023, 30014, 30531, 31384
Polk Audio	30189
Proscan	31254
RCA	31023, 31254, 30531
Sansui	30189
Sony	31759, 30158, 31758
Stereophonics	31023
Sunfire	31313
Technics	31308, 31518
Victor	30074
Wards	30158, 30189, 30014
Yamaha	30176, 31176

### Setup Codes For Cable Boxes

ABC	00003, 00008
Americast	00899
Bell South	00899
Comcast	01982
Digeo	01187
Director	00476
General Instrument	00476, 00810, 00276, 00003
GoldStar	00144
Hamlin	00009, 00273
Jerrold	00476, 00810, 00276, 00003
Memorex	00000
Motorola	01376, 00476, 00810, 00276, 01187, 01254
Pace	01877, 00237, 00008
Panasonic	00000, 00107, 01982
Paragon	00000
Philips	01305, 00317
Pioneer	01877, 00877, 00144, 00533
Pulsar	00000
Quasar	00000
Regal	00279, 00273
Runco	00000
Samsung	00144
Scientific Atlanta	01877, 00877, 00477, 00008
Sony	01006
Starcom	00003
Supercable	00276
Torx	00003
Toshiba	00000
Zenith	00000, 00525, 00899

### Setup Codes For DVD Players

Accurian	21416
Aiwa	20641
Akai	20695, 20899, 21089
Alco	20790

Allegro	20869
Amphion Media	21245
AMW	21245
Apex Digital	20672, 20830, 21056, 21061
Argo	21023
Aspire Digital	21168
Audiovox	20790, 21121, 21122
Blue Parade	20571
Broksonic	20695, 20868, 21419
Cinea	20831
Cinego	21399
CineVision	20876, 20833, 20869
Citizen	20695, 21277
Coby	20778, 21086, 21107, 21351
Craig	20831
CyberHome	20816, 20874, 21023, 21129
Daewoo	20705, 20833, 20869, 21169, 21172, 21254, 21242, 21441
Denon	20490, 20634
Disney	20675, 21270
Durabrand	21127
DVD2000	20521
Emerson	20591, 20675, 20821, 21268
Enterprise	20591
ESA	20821, 21268
Funai	20675, 21268, 21334
Gateway	21073
GE	20522, 20815
Go Video	20744, 20715, 20741, 20783, 20833, 20869, 21044, 21075, 21099, 21304
GoldStar	20741
Harman/Kardon	20582, 20702
Hitachi	20573, 20664, 21247
Hiteker	20672
iLo	21348, 21472
Initial	21472
Insignia	21268
Integra	20627
JBL	20702
JVC	20558, 20623, 20867, 21164, 21602
Kawasaki	20790
Kenwood	20490, 20534
KLH	20790
Koss	20651
Lenox	21127
LG	20591, 20741, 20869
LiteOn	21058, 21416, 21440
Magavox	20646, 20675, 21506
Panasonic	20490
Philips	20646
Pioneer	20631
Polaroid	21086
RCA	20522
Samsung	20490, 21470
Sharp	20675
Sony	21033, 21070, 21431, 21536
Sylvania	20675
Zenith	20741

### Setup Codes For DVD-R Players

### Setup Codes For TVs

Sansui	20695
Sanyo	20695, 20873
Sharp	20630, 20675, 20752, 21256
Shinsonic	20533, 20839
Sonic Blue	20869, 21099
Sony	20533, 21533, 20864, 21033, 21070, 21431, 21536
Sova	21122
Superscan	20821
Sylvania	20675, 20821, 21268
Symphonic	20675, 20821
Teac	20790
Technics	20490, 20703
Theta Digital	20571
Tivo	21503
Toshiba	20503, 20695, 21045, 21154, 21503, 21769
Urban Concepts	20503
US Logic	20839
Venturer	20790
Victor	20778, 21086, 21107, 21351
Denon	10145
Denstar	10628
Dumont	10017
Durabrand	10463, 10180, 10178, 10171, 11034
Dell	11080, 11178
Daewoo	10451, 10092, 11661, 10623, 10661, 10672
Dell	11080, 11178
Optimus	10154, 10250, 10166, 10650
OptomA	10887
Optonica	10093, 10165
Orion	10236, 10463, 11463
Panasonic	10250, 10051, 10055, 10650, 11291, 11941
Penney	10047, 10156, 10051, 10060, 10178, 10300, 11347
Petters	11523
Philco	10054, 10030
Philips	11454, 10054, 10690
Pilot	10030
Pioneer	10166, 10679, 10866
Polaroid	10765, 10865, 11262, 11276, 11314, 11341, 11523, 11991
Portland	10092
Prima	10761, 10783, 10815, 10817, 11933
Princeton	10700, 10717
Prism	10051
Proscan	11447, 10047, 11347
Proton	10178, 10466
Pulsar	10017
Quasar	10250, 10051, 10055, 10165, 10650
RadioShack	10047, 10154, 10180, 10178, 10300, 10165
RCA	11447, 10047, 10090, 10679, 11047, 11147, 11247, 11347
Realistic	10154, 11958, 12002
Runco	10017, 10030
Sampo	1030, 11755
Samsung	1060, 10812, 10702, 10178, 10300, 10766, 10814, 11060, 11903
Sansui	10463
Sony	10154, 10088, 10159
Scotch	10178
Scott	10236, 10180, 10178
Sears	10047, 10054, 10154, 10156, 10178, 10171, 10159
Sharp	10093, 10165, 10386, 11602
Sheng Chia	10093
Simpson	10187
Sony	11100, 10000, 11317
Soundesign	10180, 10178
Squareview	10171
SSS	10180
Starlite	10180
Studio Experience	10843
Superscan	10093, 10864
Supreme	10000
SVA	10748, 10587, 10768, 10865, 10870, 10871, 10872
Sylvania	10054, 10030, 10171, 11271, 11314
Symphonic	10171
Syntax	11144, 11240, 11331
Techview	10847
Toshiba	10845, 11656
Viewsonic	10857, 10864, 10885, 11330, 11578
Vizio	10864, 10885, 11756, 11758
Westinghouse	10885, 10889, 10890, 11282, 11577
Zenith	11265

### Setup Codes For TVs