

battery

Scientific Atlanta DP 2203C

xfinity®

INSTALLATION AND REPLACEMENT

Enclosed is the battery that you requested for your voice modem. The battery is easy to install as outlined in the instructions below.

1. Unplug your CDV modem from the power outlet to install the battery.
2. Gently press the battery compartment cover on the front of the modem to open the cover and gain access to the battery compartment.
3. Move the battery lock upward and to the right to the unlocked position.
4. Insert the new battery into the battery compartment until it clicks into place and close the battery compartment cover (Figure A).



5. Slide the battery lock downward and to the left to the Locked position (Figure B).
6. Gently raise the battery compartment door until it clicks and closes securely.



Once the battery installation is complete, plug your CDV modem back into the power outlet. Check for a dial tone. The battery can take up to 24 hours to fully recharge.

Thank you!

Comcast.

