

battery

xfinity[®]

INSTALLATION AND REPLACEMENT

Enclosed is the battery that you requested for your voice modem. The battery is easy to install as outlined in the instructions below.

- 1.** Unplug your CDV modem from the power outlet to install the battery.
- 2.** Place the SBV5220 on its side and remove the battery cover on the bottom.
- 3.** Slide the battery into the battery compartment until it is fully seated. The battery is keyed so that it cannot be installed incorrectly. Make sure that the pull-tab on the battery is accessible and does not prevent the battery cover from closing properly.



- 4.** Re-install the battery cover with the locking tabs seated downward, and then push the cover forward.

Once the battery installation is complete, plug your CDV modem back into the power outlet. Check for a dial tone. The battery can take up to 24 hours to fully recharge.

Thank you!

Comcast.

