

XFINITY® ON THE X1 ENTERTAINMENT OPERATING SYSTEM®

Here are some tips to help familiarize you with the new guide.

For more - go to xfinity.com/x1support or **Settings > Help*** on your TV to watch tutorial videos.

USING THE GUIDE:



Watch as you browse

Continue watching your program while browsing the Guide, On Demand, and more. Video will always be playing full screen behind the Guide. Go to "Settings" to change the background darkness level to make your program more visible or **press "B" on the remote** for a smaller video window.



Skip to tomorrow's listings in the guide

While browsing the guide, **press the fast forward button** to jump ahead a day or the **rewind button** to jump back a day. Both will jump 24 hours from your current position in the guide.



See what's on now

You can continue watching your program while browsing what else is airing now. **Press the Right Arrow** while watching TV to see a list of what's currently on all of your channels.



See what's on next

Press the Right Arrow twice while watching TV to browse the full programming schedule for a specific channel up to two weeks out.



Filter your guide

Press "Guide" twice on your remote to choose a filtered Guide view like Favorites, HD, Sports and more.



View what's on your favorite channels

To set up favorite channels, **Press "Guide"** on your remote control. Scroll left to highlight a channel logo and number, press "OK", and select "Favorite" from the options.

To view the guide by Favorites, **Press "Guide" twice** on your remote. Select "Favorites" as your Guide view to see what's on only those channels.



See what's trending now

Look for the Twitter icon on buzz worthy shows within the grid guide.

NAVIGATION TIPS:




Go back in the menu

While navigating the Guide or On Demand, **press "Last"** to go back a step or keep pressing until you return to live TV.



Read full show descriptions

If a program description runs off screen, you can **press "Info"** on your remote to expand the screen and read the full program description.



Video controls

You're always in control. To access on-screen playback controls, including Closed Captioning, **press the Down Arrow twice** on your remote while watching TV.



Search even faster

Search even faster using the keypad on your remote to spell out a title, sports team or personality. For example, for "Blacklist" start pressing 2522. You can start typing at any point — while watching TV, or in the guide.

*Note that not all set-top boxes have access to the Help menu

NAVIGATION TIPS: *cont.*



Never miss a score

Press the **"C"** button to launch and use the sports app to track multiple games at once and check the latest scores and standings, all while watching another game.



Last watched

Press **"Last"** while watching TV to see the last channels you've watched, as well as the last DVR recordings or XFINITY On Demand™ programs you've watched.



Change your background darkness level

Adjust your background darkness level in **Settings > Preferences** to see more or less of the video playing in the background.



Using your remote

Your remote can navigate the menus, provide shortcuts, and control your TV or audio device. To pair your device with a TV or audio device, go to comcast.com/remotes for instructions. To pair your remote to your set-top box so you can aim it anywhere, follow the instructions on the back of the remote.



Jump back to Live TV


After pausing or replaying live TV, you can return to the live airing point by pressing **"Exit"**.



Control live TV


With your DVR, you can Pause, Rewind or get an instant Replay on Live TV. If you are watching on a non-DVR set-top box, you can still control Recordings & On Demand, but not Live TV.

SAVED (DVR, FAVORITES, PURCHASES):



See what's included in Saved

Saved includes all of your recorded shows from your DVR, upcoming scheduled recordings, Favorites (shows, movies, personalities, and teams) and On Demand purchases.



A menu that's just "For You"

Go to "Saved" and select "For You" to see shows you've watched or recorded and new recommendations.



Manage your recordings


Use the Priority Manager in **Saved > Scheduled** to update or cancel any of your series recordings.

Record up to four shows while watching another. Store hundreds of shows, which you can start watching in one room and finish in another.



Use the "D" button to delete

The "D" button on your remote can be used to delete any recording or to cancel a scheduled recording. Just press **"D"** to delete a single program or a folder of programs.



Restore deleted recordings

You can restore deleted programs by navigating to **Saved > Recordings**. The last folder on the page is called **"Recently Deleted"**. Press **"OK"** on your remote to see all of your recently deleted recordings, and select the title of the recording you wish to restore. Press **"OK"** and select **"Restore"**.



Keep up with your favorite shows

Progress bar indicators make it easy to know what to watch next. Look for **"watched"** indicators to see which episodes you've already watched. Select **"Mark Unwatched"** to clear the indicator.